

SCREENWOOD

PANELS^{II}



Cleaning and Maintenance

DECORATIVE FIBREBOARD

PANELS with Navurban™ surfaces are easy to clean using a cloth dampened with warm water and detergent. If in doubt about a particular cleaner or detergent, check with its manufacturer for the suitability. We recommend you test on a small area or sample prior to applying to the surface.

Avoid the use of acetone or trichloroethylene for cleaning purposes. Use of abrasive cleaners, powders, scouring pads, steel wool, sandpaper etc. can damage the finish and make the surface susceptible to staining. Accidental spills or splatters from harsh materials should be wiped off immediately, and the area cleaned thoroughly with a damp cloth. Examples of these materials are: Ceramic cooktop cleaners, tub and tile cleaners, chlorine bleach, oven cleaners, and harsh detergents. Avoid dragging or knocking heavy objects against the surface.

SOLID TIMBER

Solid Timber PANELS prefinished in internal grade coatings will look their best with periodic dusting. Should the panels require cleaning, we recommend wiping the panels down with a clean damp cloth. If the panels are subjected to any moisture, please wipe them down immediately. Internal coatings should not be wet down or hosed as this will negatively impact the coating.

Disclaimer: The information, opinions, advice and recommendations provided have been prepared with due care. They are offered only for the purpose of providing some useful and helpful assistance to specifiers and their clients. Whilst every effort has been made to ensure that this is in accordance with current technology, it is not intended as an exhaustive statement of all relevant knowledge.

