

Install Guide

Stix<sup>®</sup> MR  
Stix<sup>®</sup> FR

The prefinished decorative architectural battens for design flexibility.



# Stix®

## Installation Guide

### Suitable Applications

Stix® are loose decorative timber battens, available in a range of sizes and profiles and prefinished in NAVURBAN™ finishes. Stix® integrates seamlessly with our Modulo®, Soundlina® and Panels ranges, or can be used as standalone decorative battens.

Stix® battens are available in Group 2 and Group 3 fire-rated substrates. They are not suitable for use in wet areas or external use.

### Before you begin

---

#### Fixing

- Stix® is not suitable for structural applications.
- The olefin film wrapping requires a small overlap to one face of the profile. We recommend that the overlap is installed against the wall or surface that the profile is being adhered to.

#### Cutting

- Cutting of Stix® should be done by qualified trades using a drop saw or panel saw with carbide tipped blades and can be cut with the use of routers, trimmers and other joinery tools typically used when fabricating MDF.

#### Profile Weights

- Please refer to the Technical Data Sheets found at [screenwood.com.au/range/stix-mr/](https://screenwood.com.au/range/stix-mr/) or contact our team for information.

#### Moisture

- Although Stix® MR is manufactured from moisture resistant (MR) MDF, the end grain of Stix® cannot get wet. Ends should be sealed in installations where accidental ingress of water or moisture may occur.
- Stix® used for walls should be kept at least 20mm above a floor surface and care must be taken when floors are being mopped/cleaned. The warranty does not cover damage from water ingress.

#### Care and Maintenance

- NAVURBAN™ surfaces are easy to clean using a damp cloth and mild soap and warm water or non-abrasive wood cleaning products.
- We recommend you test on a small area or sample prior to applying to surface.

# Stix® Installation Guide

Figure 1. Direct Fix and Rebated Direct Fix, end view




Figure 2. Keyhole/ Button Fix, end view





Figure 3. Keyhole/ Button Fix





We're ready to help.

**Screenwood Australia**

432 The Boulevard  
Kirrawee NSW 2232  
Australia

**+61 2 9521 7200**

**hello@screenwood.com.au**

**Be inspired**

Explore our product innovations and  
get inspired at **screenwood.com.au**

**Acknowledgment of Country**

In the spirit of reconciliation, we acknowledge the Traditional Custodians of Country throughout Australia and their connections to land, sea and community. We pay our respect to their Elders past and present and extend that respect to all Aboriginal and Torres Strait Islander peoples today.

**Screenwood for all**

Our products are for everyone, and so is our workplace. We believe in constantly building a diverse and inclusive culture for a more equitable world.

**Disclaimer** All care is taken in the preparation of the information and published materials produced by Screenwood. However, Screenwood does not make any representations or give any warranties about its accuracy, reliability, completeness or suitability for any particular purpose.